

Your Doctor has asked you to collect a Mid-Stream Urine specimen (MSU) for Pathology testing

Males:

Wipe the tip of your penis with a sterile water wipe.
Throw the wipe in the bin and do this two more times.

(If applicable) Withdraw the foreskin and urinate the first, little bit into the toilet and then urinate into the yellow-topped container. This is the mid-stream urine.

Try and half fill the container.
Screw the lid on the container to close tightly.

Write your full name, date of birth, and the time and date of the collection on the container.

Take the container and your request form to an Austin Pathology Collection Centre.

Note: A minimum of 10mls is required for this test.

www.austinpathology.org.au

03 9496 5472

